SPRING PRE-FLIGHT PREP CHECKLIST 10 INDRO PROBOTICS



AIRCRAFT	
0000000	Inspect batteries Remove swollen or damaged batteries from service Charge and balance cells in flight batteries Inspect propellers Inspect airframe Check for and install firmware updates Check health of all batteries in app Check app defaults and restore preferences Check cables for tablet/phone connection
ADMINISTRATIVE	
	Confirm/regain recency Check aircraft manual version Update docs in NAV drone app Ensure flight kit equipment is functional and hasn't been "borrowed" (first aid kit, fire extinguisher, tools, memory card) Check and charge batteries of ancillary devices (VHF and two-way radios, tablet) Ensure VTA/VNC charts and CFS are up to date
PERSONAL	
	Review and update SOP for normal operations Familiarize with new app features Get reoriented with information displays on flight app Practice distance and height estimates when flying Mock through all emergency procedures Ensure no new medications/health changes will affect flight safety